

TECHNICAL BRIEF

SHORT-TERM CHEMICAL SANITATION OF ZETA PLUS[®] H SERIES AND ZETA PLUS MAXIMIZER[™] H SERIES FILTER CARTRIDGES WITH A CHEMICAL SANITIZER (OXONIA ACTIVE[®])

INTRODUCTION:

Filters used in Food and Beverage applications are routinely sanitized to reduce the bioburden populations and provide a sanitized (if not sterile) environment during production. Hot water sanitation is generally preferred over chemical treatments for short-term sanitation. It is typically applied prior to the beginning of a production run and at the end of a production run, to sanitize the production equipment. When the use of hot water cannot be conveniently employed, chemical sanitation is the preferred and recommended procedure.

Oxonia Active (a commercial sanitizer produced by Ecolab, Inc. containing a mixture of hydrogen peroxide and peroxyacetic acid) can be easily employed for chemical sanitation. The temperature, concentration, and duration of the sanitation cycle are important considerations when using this chemical sanitizer. In general, these parameters should be optimized to ensure proper sanitation and if required, should be validated on-site. An equally important consideration is the compatibility of the filter media with the sanitizer of choice, in this case Oxonia Active.

At all times, consideration should be given to worker safety and compliance with local regulations regarding the use of sanitizing chemicals.

RECOMMENDED SHORT TERM SANITATION GUIDELINES

- At the end of the filtration cycle, warm water regenerate the filter according to CUNO Technical Brief LITDCO2 (Warm Water Regeneration of Zeta Plus Filter Cartridges).
- Drain the filter housing of the remaining warm water. Do not proceed to the chemical sanitation step until the filter housing has cooled to ambient temperature.
- Slowly fill the filter housing with Oxonia Active at a maximum concentration of 1.0% v/v. Follow all safety precautions provided by the sanitizer supplier.
- Once the filter housing is filled with Oxonia Active, close all housing valves and allow the sanitizer to remain in the housing for 30 minutes.
- After sanitizing, and before use, drain the sanitizing solution from the filter housing. Follow all safety precautions and disposal recommendations provided by the sanitizer supplier.
- To remove any residual sanitizing solution in the filter media, flush the filter in the forward direction for 15 minutes with filtered, ambient temperature water at a flux rate of 0.5 GPM/ft² of filter media installed.
- CUNO Zeta Plus H Series media and H Series Zeta Plus Maximizer media can be exposed to Oxonia Active at a maximum concentration of 1.0% v/v for a maximum of 40, 30 minute cycles

Additional technical service can be provided by your local CUNO Distributor or the CUNO Scientific Applications Support Services (SASS) department, (800)243-6894.





a 3M company

CUNO Filtration Asia Pte Ltd
18 Tuas Link 1 (3rd Floor)
Singapore 638599

CUNO Pacific Pty Ltd
140 Sunnyholt Road
Blacktown, NSW 2148
Australia

CUNO Latina Ltda
Rua Amf Do Brasil 251
18120 Mairinque-Sp
Brazil

Cuno Filtration Shanghai Co, Ltd
No. 2 Xin Miao San Rd,
Xin Miao Town,
Song Jiang District,
Shanghai. China. 201612

CUNO K.K.
Hodogaya Station
Building 6F
1-7 Iwai-cho, Hodogaya-ku
Yokohama 240 Japan

CUNO Ltd
21 Woking Business Park
Albert Drive
Woking, Surrey GU215JY
United Kingdom

Cuno Incorporated

400 Research Parkway
Meriden, CT 06450, U.S.A.
Tel: (800) 243-6894
(203) 237-5541
Fax: (203) 630-4530
www.cuno.com